
Removal


1 Unscrew fastening screws (1) of licence plate lamps and remove licence plate lamps.



Sedan, coupe

Installation

2 For installation proceed vice versa.



T-sedan